

PIPELINE BOTTOMING OUT KIT

Effective dispense cleaning in 25 easy-to-follow steps

HEALTH AND SAFETY NOTES

It is important to carry out a local risk assessment before using these products. We would always recommend the use of safety goggles and gloves.



01
Turn off the cooler
(Ideally 2hrs in advance)



02
Turn on cleaning gas



03
Disconnect the beer



04
Clean Keg Coupler



05
Connect to the cleaning ring



06
Use the pre-measured container
1 container = 25litrs of solution
2 containers = 50 litrs of solution



07
Fill vessel with BOK and top up with water



08
Place CIP tags on taps to show clean in progress



09
Bleed fobs until full of cleaning solution



10
Remove dispense tap fittings, place in glass



11
Draw cleaning fluid through tap until visible



12
Soak for 10 minutes



13
Pull off 1 pint of fluid per line



14
Soak for 10 minutes



15
Pull off 1 pint of fluid per line



16
Soak for 10 minutes



17
Empty & rinse vessel, fill with water & reconnect



18
Bleed fob detectors & rinse bleed tube



19
Flush out cleaning solution with a minimum of 10 litres of water per line



20
Inspect rinse water for debris - ensure none



21
Check rinse water with test papers
Blue=Pipeline present/Pink=Rinse complete



22
Rinse tap fittings & refit



23
Turn on cooler



24
Reconnect the beer



25
Now serve

FOR THE FULL SET OF PROCEDURE INSTRUCTIONS PLEASE SEE OUR PIPELINE PROTOCOL MANUAL

Contact Chemisphere UK today for more information regarding our products.

Freephone: 0800 0188 062
Email: contactus@chemisphereuk.co.uk
Fax: 01536 411 210
Website: www.chemisphereuk.com



chemisphere uk ltd
the home of purple pipeline